

while maintaining a low water content in the mixture. This is particularly important in cold weather when delayed set results in prolonged bleeding.

- b. *NEVER* sprinkle or trowel dry cement into the surface of plastic concrete to absorb bleed water. Remove bleed water by dragging a garden hose across the surface. Excessive bleeding of concrete can be reduced by using air-entrained concrete, by modifying mix proportions, or by accelerating the setting time.
- c. *DO NOT* perform any finishing operations with water present on the surface or while the concrete continues to bleed. Initial screeding must be promptly followed by bull floating. Delaying bull floating operations can cause bleed water to be worked into surface layer. Do not use a jitterbug, as it tends to bring excess mortar to the surface. *DO NOT* add water to the surface to facilitate finishing operations.
- d. Do not place concrete directly on polyethylene vapor retarders or non-absorptive subgrades. This can contribute to problems such as dusting, scaling, and cracking. Place 3 to 4 inches [75 to 100 mm] of a trimmable, compactible fill, such as a crusher-run material, over vapor retarders or non-absorptive subgrade prior to concrete placement. When high evaporation rates exist, lightly dampen absorptive subgrades just prior to concrete placement, ensuring that water does not pond or collect on the subgrade surface.
- e. Provide proper curing by using liquid membrane curing compound or by covering the surface with water, wet burlap, or other curing materials as soon as possible after finishing to retain moisture in the slab. It is important to protect concrete from the environment at early ages.
- f. Placing concrete in cold weather requires concrete temperatures exceeding 50°F [10°C] as well as an accelerating admixture.

HOW to Repair Dusting

- a. Sandblast, shot blast, or use a high-pressure washer to remove the weak surface layer.
- b. To minimize or eliminate dusting, apply a commercially available chemical floor hardener, such as sodium silicate (water glass) or metallic zinc or magnesium fluosilicate. In compliance with manufacturer's directions, on thoroughly dried concrete. If dusting persists, use a coating, such as latex formulations, epoxy sealers, or cement paint.
- c. In severe cases, a serviceable floor can be obtained by wet-grinding the surface to durable substrate concrete. This may be followed by properly bonded placement of a topping course. If this is not practical, installation of a floor covering, such as carpeting or vinyl tile covering, is the least expensive solution to severe dusting. This option will require some prior preparation since adhesives for floor covering materials will not bond to floors with a dusting problem and dusting can permeate through carpeting.

References

1. *Guide for Concrete Floor and Slab Construction*, ACI 302.1R. American Concrete Institute, Farmington Hills, MI.
2. *Slabs on Grade*, Concrete Craftsman Series CCS-1, American Concrete Institute, Farmington Hills, MI.
3. *Concrete Slab Surface Defects: Causes, Prevention, Repair*, IS177, Portland Cement Association, Skokie, IL
4. *The Effect of Various Surface Treatments, Using Zinc and Magnesium Fluosilicate Crystals on Abrasion Resistance of Concrete Surfaces*, Concrete Laboratory Report No. C-819, U.S. Bureau of Reclamation.
5. *Residential Concrete*, National Association of Home Builders, Washington, DC.
6. *Trouble Shooting Guide for Concrete Dusting*, Concrete Construction, April 1996.

Follow These Rules to Prevent Dusting

1. Use moderate slump concrete not exceeding 5 inches [125 mm].
2. Do not start finishing operation while the concrete is bleeding.
3. Do not broadcast cement or sprinkle water on concrete prior to or during finishing operations.
4. Ensure that there is adequate venting of exhaust gases from gas-fired heaters in enclosed spaces.
5. Use adequate curing measures to retain moisture in concrete for the first 3 to 7 days and protect it from the environment, especially freezing.