

to reduce the heat generated by cement hydration, such as the use of an ASTM Type II moderate heat cement and the use of pozzolans and slag can reduce potential problems with high concrete temperature. Advance timing and scheduling to avoid delays in delivery, placing and finishing is essential. Trucks should be able to discharge immediately and adequate personnel should be available to place and handle the concrete. When possible, deliveries should be scheduled to avoid the hottest part of the day. Limits on maximum concrete temperature may be waived by the purchaser if the concrete consistency is adequate for the placement and excessive water addition is not required.

In the case of extreme temperature conditions or with mass concrete, the concrete temperature can be lowered by using chilled water or ice as part of the mixing water. The ready mixed concrete producer uses other measures, such as sprinkling and shading the aggregate prior to mixing, to help lower the temperature of the concrete.

If low humidity and high winds are predicted, wind-breaks, sunscreens, mist fogging, or evaporation retardants may be needed to avoid plastic shrinkage cracking in slabs.

References

1. Hot Weather Concreting, ACI 305R, American Concrete Institute, Farmington Hills, MI.
 2. Cooling Ready Mixed Concrete, NRMCA Publication No. 106, NRMCA, Silver Spring, MD.
 3. Effect of Temperature and Delivery Time on Concrete Proportions, R.D. Gaynor, R.C. Meininger, T.S. Khan, NRMCA Publication 171, NRMCA, Silver Spring, MD.
 4. Hot-Weather Concreting, Chapter 11 in Design and Control of Concrete Mixtures, Portland Cement Association, Skokie, IL.
 5. Keeping Concrete Cool in the Heat of Summer, K.C. Hover, Concrete Construction, June 1993.
-



Follow These Rules for Hot Weather Concrete

1. Modify concrete mix designs as appropriate. Retarders, moderate heat of hydration cement, pozzolanic materials, slag, or other proven local solutions may be used. Reduce the cement content of the mixture as much as possible, while ensuring the concrete strength will be attained.
2. Have adequate manpower to quickly place, finish and cure the concrete.
3. Limit the addition of water at the job site—add water only on arrival at the job site to adjust the slump. Water addition should not exceed about 2 to 2½ gallons per cubic yard (10 to 12 L/m³). Adding water to concrete that is more than 1½ hours old should be avoided.
4. Slabs on grade should not be placed directly on polyethylene sheeting or other vapor retarders. Cover the vapor retarder with a minimum 4-inch (100 mm) layer of compactible, easy-to-trim, granular fill material.
5. On dry and/or hot days, when conditions are conducive for plastic shrinkage cracking, dampen the subgrade, forms and reinforcement prior to placing concrete, but do not allow excessive water to pond.
6. Begin final finishing operations as soon as the waater sheen has left the surface; start curing as soon as finishing is completed. Continue curing for at least 3 days; cover the concrete with wet burlap and plastic sheeting to prevent evaporation or use a liquid membrane curing compound, or cure slabs with water (See CIP 11). Using white pigmented membrane curing compounds will help by indicating proper coverage and reflecting heat away from the concrete surface.
7. Protect test cylinders at the jobsite by shading and preventing evaporation. Field curing boxes with ice or refrigeration may be used to ensure maintaining the required 60 to 80°F (17 to 27°C) for initial curing of cylinders. (See CIP 9)
8. Do not use accelerators unless it is common practice to avoid plastic shrinkage cracking and expedite finishing operations.